





FOLLOW THESE FIVE STEPS FOR FIVE YEARS OF PROTECTION

STONEFENGE

STONEFLENGE

PRIOR TO INSTALLATION

- 1. PolyXsand performs best with proper drainage. Pavers should be installed in accordance with CHMA guidelines.
- 2. Install on a clean dry surface. We recommend using our complete paver cleaning product lineup.



3. Ambient temperature should be above 40 degrees for a minimum of 24 hours.

4. At least no rain 12 hours before or after installation

For reinstalls. A minimum of 1" joint depth is required

5 STEP INSTALLATION

- 1. Distribute PolyXsand evenly across the surface. (Do not dump in a large pile)
- 2. Sweep into joints until full

3. Compact the sand using a vibratory compactor with rubber matt (best) or hand tamper with rubber matt to make the sand as dense as possible. (The denser the sand the longer it will last)

4. Refill joints (if necessary) until 1/8in below the paver. It is important not to over fill the joints. A leaf blower or broom can be used to set the correct height. Pick up any large amounts of left over sand with a broom and shovel. Use a leaf blower to blow off any fine particles.

5. Use a hose with a mist setting to wet the entire surface. Avoid using high pressure, as it may displace the sand from the joints. Repeat this process 3–4 times until the joints are fully saturated, indicated by water beginning to puddle on the surface.

*tip. More water is better than less water.

*tip. Use a leaf blower (on idle) to remove any puddling water without disturbing the joint. (if necessary)



CLEANERS PREMIUM PAVER AND STONE PROTECTION & MAINTENANCE



SURE CLEAN

MULTI-USE CLEANER

ELIMINATES DEEP-SET DIRT, GRIME, TIRE SCUFFING AND ENVIRONMENTAL SOILING. RESTORES & CLEANS A SURFACE

OIL EXTRACTOR

TARGETED CLEANING ACTION

DISSOLVES, ENCAPSULATES AND REMOVES OIL STAINS

STAIN & RUST BUSTER

CLEANS A WIDE RANGE OF ORGANIC, NON-GREASY STAINS



EFFLORESCENCE?

CLEANS TOUGH EFFLORESCENCE, MINERAL & SALT DEPOSITS

